

Model/Modelo: PIV7148

**PREMIUM
LEVELLA.****STEAM & DRY IRON
PLANCHA A VAPOR**

www.premiumlevela.com

USER MANUAL / MANUAL DE INSTRUCCIONES

Use and care manual. Important safeguards. This product is for domestic use only.
Manual de uso y cuidado. Precauciones importantes. Este producto es para uso doméstico únicamente.

Thank you for purchasing our product, please read these instructions before use.

Specifications:

Model: PIV7148
Functions: Spraying, Dry Ironing, Steam
Rated parameter: 120V~60Hz 1200W
Ironing Temp: 50-220°C
Type of Fabric: Nylon, Silk, Wool, Cotton, Linen

Safety Instructions:

- Before using for the first time, please check if the voltage rating on the type plate corresponds to the mains voltage in your home, if not, please contact with the seller.
- Use a grounded wall socket; the cord and plug must be dry.
- Unfold the AC cord completely before using.
- Make sure to unplug the appliance from the socket when leaving the iron even for a short while, and stand the iron on its end. Please leave the iron away from children. Take care of the iron when it is on.
- The iron will reach high temperatures when used; never touch it with your hand or use close to flammable products in order to avoid accidents.
- Caution: Unplug the appliance from the socket before filling the iron with water or pouring out the remaining water.
- Minerals in the water will generate scaling and block the steam hole, therefore it is recommended to use distilled water.
- Use the iron only as described in this instruction manual.
- Close supervision is necessary when any appliance is used near children. Do not leave an iron unattended while connected or on an ironing board. Burns can occur from touching hot metal parts, hot water, or steam.
- Keep the iron out of reach of children.
- The iron should never be left unattended while it is connected to the mains supply.
- Unplug the iron from the mains electrical supply before cleaning, filling with water or emptying the water tank and immediately after use.
- Never operate the iron with a damaged power cord or plug, or after it has fallen or has been damaged in any way. To avoid the risk of electric shock, do not disassemble the iron, take it to a qualified serviceman for examination and repair.
- Do not let the cord touch hot surfaces.
- To protect against risk of electric hazards, do not immerse the iron in water or any other liquid.



(Lea estas instrucciones detenidamente antes de usar y guarde este manual para uso futuro)


12

1

- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.

BEFORE FIRST USE:

- It is normal for small amount of smoke to be produced the first time the iron is used; this will quickly disappear.
- When using the steam function for the first time, do not direct the steam towards the laundry, as there could be debris from the steam vents.
- Before using for the first time, remove any sticker or protective foil from the soleplate. Clean the soleplate with a soft cloth.
- Keep the soleplate smooth: avoid hard contact with metal objects (such as clothes rack, buttons, or zippers).
- Pure woolen fabrics (100% wool) may be pressed with the iron set to a steam position. Preferably set the steam regulator to HI and use a dry pressing cloth.

Components:

A---Spray Nozzle B---Water Filling Cover C---Steam Knob D---Spray Button
E---Thermostat Knob F---Water Tank G---Power Indicator Light

Filling with Water:

- Set the steam regulator to O (=no steam) (only for steam iron).
- Hold the iron by hand and slant the iron 45° down, open the Water Filling Cover if any.
- Fill the water in the tank through the Water-Filling Hole, if the water is too hard, it is advisable to use distilled water.

2

Resolución de problemas sencillos:

Problema	Razón posible	Solución
No hay suficiente calor o calor demasiado bajo	El dial del termostato no está ajustado correctamente.	Coloque el termostato en la posición correcta.
No hay vapor o hay fugas	El tanque de agua no está lleno correctamente	Vuelva a llenar el depósito de agua según las instrucciones de llenado de agua.
No hay vapor	El dial del termostato no se ha configurado en el rango de vapor	Ajuste el dial del termostato al rango de vapor.
	Compruebe si el regulador de vapor se ha colocado en la posición de vapor.	Coloque el regulador de vapor en el rango de vapor.
	No hay o muy poca agua en el tanque.	Llene de agua el tanque
Fugas de agua por la suela	El dial del termostato está fuera del rango de vapor.	Coloque el termostato en el rango de vapor.
	La temperatura todavía no es lo suficientemente alta.	Presione el botón de vapor solo después de que la luz indicadora se apague.
Muy poco vapor	El agua en el tanque está por encima de la posición máxima.	Vierta el agua extra
	El regulador de vapor está en la posición incorrecta.	Coloque el regulador de vapor en la ubicación adecuada
	El orificio de vapor o el tanque están bloqueados.	Limpie el agujero con agua destilada.
No atomiza (Spray)	Muy poca agua en el tanque.	Llene de agua el tanque
	No hay suficiente presión o aire en el interior	Presione la boquilla de pulverización y presione el botón de pulverización varias veces de forma continua.
	No hay o muy poca agua en el tanque.	Llene de agua el tanque

Si después de probar las soluciones mencionadas anteriormente para resolver problemas con la plancha aún no funciona normalmente, envíela a un agente de servicio para su reparación.

11

Tipo de tela y posición del Termostato:

Cuidado: Por favor note que este signo en la etiqueta significa que el artículo no debe ser planchado

Instrucciones en la etiqueta	Tipo de tela	Termostato
	Nylon Seda	MIN
	Lana	↑
	Algodón	
	Lino	

Precaución: si el tejido consta de varios tipos de fibras, seleccione siempre la temperatura de planchado más baja de la composición de esas fibras.

Limpieza y Mantenimiento:

Antes de limpiar, retire el enchufe del tomacorriente y deje que la plancha se enfríe lo suficiente.

- Limpie la suela con un paño húmedo y un limpiador no abrasivo (líquido).
- Si hay fibras adheridas a la suela, use un paño húmedo con vinagre para limpiar la suela.
- Nunca use limpiadores fuertes para evitar dañar la suela.
- Si hay residuos minerales bloqueando el orificio de vapor, retirelos con un palillo de dientes; no dañe la superficie de la suela.
- Coloque la plancha sobre su extremo y deje que se enfríe lo suficiente, saque el agua restante de tanque y coloque el regulador de vapor en la posición "O".

10

3

- Wipe off the water over the exterior; pour out the remaining water after use.

Dry Ironing:

- Before running the iron, please classify the clothes as per its washing label, as it will be quicker for the iron to heat up than to cool. The clothes with lower ironing temperature (such as synthetic fabric, silk etc) shall be ironed first, and then iron the clothes with higher temperature ironing (such as wool, cotton and linen etc).
- Stand the iron on its end, and turn the thermostat dial to the MIN position.
- Plug in the iron and select the temperature by turning the thermostat dial. If there is water in the reservoir, turn the steam regulator to OFF position. Wait until the indicator light goes off showing that the required temperature has been reached.

Steam Ironing:

- Fill water in the iron tank as per the water-filling instructions.
- Plug the appliance in the socket.
- Set the thermostat dial to MAX position as per the temperature indicator, and steam iron will be available; otherwise, water may leak from the soleplate.
- The ironing temperature has been reached when the indicator light goes off.
- Set the steam regulator as needed, increase or decrease the steam output by rotating the steam regulator.

Caution: Synthetic Fabric, Nylon, Synthetic Silk and Silk cannot be ironed using steam, as it will damage the finish of surface.

Spraying Methods:

- Fill the water in the iron as per water-filling instructions.
 - Press the water spray button.
- Note: No matter if you are steam ironing or dry ironing is, Spray will always be available in any case.

Type of Fabric and Thermostat knob Dial Form:

Caution: Please note that this on the label means that this article may not ironed.

Instructions on Label	Type of Fabric	Thermostat dial
	Nylon Silk	MIN
	Wool	↑
	Cotton	
	Linen	

Caution: If the fabric consists of various types of fibers, always select the lowest ironing temperature of the composition of those fibers.

Cleaning and Maintenance:

Before cleaning, remove the plug from the socket and allow the iron to cool down sufficiently.

- Wipe off the soleplate with a damp cloth and a non-abrasive (liquid) cleaner.
- If fiber is adhered to the soleplate, use a damp cloth with vinegar to wipe off the soleplate.
- Never use strong cleaners in order to avoid damaging the soleplate.
- If scale blocks the steam hole, please remove the scale with a toothpick; do not damage the surface of the soleplate.
- Stand the iron on its end and let it cool down sufficiently, pour any remaining water out of the box, and set the steam regulator to position "O".


4

9

- Para protegerse contra el riesgo de peligros eléctricos, no sumerja la plancha en agua ni en ningún otro líquido.
- Al colocar la plancha sobre su soporte, asegúrese de que la superficie sobre la que se coloca el soporte sea estable.
- La plancha no debe usarse si se ha caído, si hay signos visibles de daño o si tiene fugas.

ANTES DEL PRIMER USO:

- Es normal que se produzca una pequeña cantidad de humo la primera vez que se utiliza la plancha; esto desaparecerá rápidamente.
- Cuando utilice la función de vapor por primera vez, no dirija el vapor hacia la ropa, ya que podría haber residuos en las rejillas de ventilación.
- Antes de usar por primera vez, retire cualquier pegatina o lámina protectora de la suela. Limpie la suela con un paño suave.
- Mantenga la suela lisa: evite el contacto fuerte con objetos metálicos (como percheros, botones o cremalleras).
- Las telas de lana pura (100% lana) se pueden planchar con la plancha en la posición de vapor. Preferiblemente coloque el regulador de vapor en HI y use un paño de planchado seco.

Componentes:

A --- Boquilla de rociado B --- Cubierta de llenado de agua C --- Perilla de vapor
D --- Botón de rociado E --- Perilla del termostato F --- Tanque de agua G --- Luz indicadora de energía

Llenado con agua:

- Coloque el regulador de vapor en O (= sin vapor) (solo para plancha de vapor).
- Sostenga la plancha con la mano e inclínela 45 ° hacia abajo, abra la tapa de llenado de agua si la hubiera.

8

5

Simple Problem Solving:

Problem	Possible Reasons	Solution
Not enough heat or too low heat	Thermostat dial is not properly set.	Dial the thermostat to the correct position.
No steam or leakage	The water tank is not filled correctly	Fill the water tank again as per Water-Filling instructions
No steam	Thermostat dial has not been set at the steam range	Adjust the thermostat dial to the steam range.
	Check if the steam regulator has been set on the steam position.	Set steam regulator on the steam range.
	No or too little water in the tank	Fill water into the tank
Leaking water from the soleplate	The thermostat dial is out of the steam range.	Set the thermostat dial to the steam range.
	The temperature is still not high enough.	Press the steam the button only after the indicator light goes off.
	The water in the tank is over the max position	Pour out the extra water
Too little steam	The steam regulator is in the wrong location.	Set the steam regulator to the proper location.
	Steam hole or tank is blocked.	Clean the hole with distilled water.
No spraying	Too little water in the tank	Fill water into the tank
	Not enough pressure or air inside	Press the spray nozzle and push the spray button several times continuously.
	No or too little water in the tank	Fill water into the tank

If after trying the solutions mentioned above to solve problems with the iron it still does not work normally, please send it to a repair agent for repair.



(Read these instructions carefully before use and keep this manual for future use)

6

Gracias por comprar nuestro producto, lea estas instrucciones antes de usar.

Especificaciones:

Modelo: PIV7148
Funciones: Pulverización, Planchado en seco, Planchado al vapor
Parámetros: 120V~60Hz 1200W
Temperatura de planchado: 50 ~ 220 °C
Tipos de tela: nailon, seda, lana, algodón, lino

Instrucciones de Seguridad:

- Antes de utilizar la plancha por primera vez, compruebe si la tensión nominal de la placa de características corresponde a la tensión de red de su hogar, en caso contrario, póngase en contacto con el vendedor.
- Utilice un enchufe de pared con conexión a tierra; el cable y el enchufe deben estar secos.
- Despliegue el cable de CA completamente antes de usarlo.
- Asegúrese de desenchar el aparato de la toma de corriente cuando deje la plancha, aunque sea por un momento, y coloque la plancha sobre su base. Deje la plancha fuera del alcance de los niños. Cuidé la plancha cuando esté encendida.
- La plancha alcanzará altas temperaturas cuando se use; nunca la toque con la mano ni la utilice cerca de productos inflamables para evitar accidentes.
- Precaución: Desenchar el aparato antes de llenar la plancha con agua o verter el agua restante.
- Los minerales en el agua pueden causar acumulación de minerales y bloquear el orificio de vapor, por lo que se recomienda utilizar agua destilada.
- Utilice la plancha solo como se describe en este manual de instrucciones.
- Es necesaria una estrecha supervisión cuando se utiliza cualquier aparato cerca de niños. No deje una plancha desatendida mientras esté conectada o sobre una tabla de planchar. Pueden ocurrir quemaduras al tocar partes metálicas calientes, agua caliente o vapor.
- Mantenga la plancha fuera del alcance de los niños.
- La plancha nunca debe dejarse desatendida mientras esté conectada a la red eléctrica.
- Desenchufe la plancha de la red eléctrica antes de limpiarla, llenarla con agua o vaciar el depósito de agua e inmediatamente después de su uso.
- Nunca opere la plancha con un cable de alimentación o enchufe dañado, o después de que se haya caído o se haya dañado de alguna manera. Para evitar el riesgo de descarga eléctrica, no desarme la plancha, llévela a un técnico de servicio calificado para que la examine y repare.
- No permita que el cable toque superficies calientes.

7